

A/V Instructions: A101



Item Storage

The room has a gray box with a DVD player, remote, and HDMI cable.



Power

Aim the TV remote at the infrared receiver (hanging below the center TV) and press the Power On button to turn on all televisions. Do not use remote to adjust any TV inputs or settings. Just use it to turn on/off.



Screens

The room has three identical TVs fed by a single HDMI input on the wall plate below the white board. Use the TV remote, aimed at the infrared receiver, to power the screens on all at once. Do not adjust anything else (aspect ratio, input) on the TVs.



Connecting Devices

Use the long HDMI cable to connect your device to the wall plate below the center TV.



DVD Player

The room is equipped with a DVD player. Use the included HDMI cable to plug it into the wall plate below the TVs. Use the DVD remote to turn it on and operate the device.



Volume and Sound

Volume is controlled by the TV remote.



Checklist for Turning Off and Shutting Down



Remove DVD from player (if used).



Disconnect device(s) and put cables back.



Turn off screens.



Put DVD player, remote, and short HDMI back in gray box. Put TV remote back in holder.